




CATALOG OF REPLACEMENT PARTS



V6B36S Shown

V Series HDR Gas Ranges

TOPS

Open Top
Hot Top
Griddle Top
Work Surface

BASES

Standard Oven
Convection Oven
Cabinet Base

*Add "B" for Cabinet Base.

*Add "S" for Standard Oven Base on
36" Models.

*Add "C" for Convection Oven Base on
36" Models.

Table of Contents

5	"B" MODEL 36", 24", 18", 12" CABINET BASE
7	"S" MODEL OVEN
9	"S" MODEL GAS MANIFOLD ASSY
11	"C" MODEL OVEN
13	"C" MODEL GAS MANIFOLD ASSY
15	36", 24" & 12" OPEN TOP BURNER
17	36"- 4 & 18"- 2 OPEN TOP BURNER
19	36" & 24" CHAR BROILER
21	36" & 18" FRENCH TOP RADIAL FIN HOT TOP
23	36", 24" & 18" THERMO CONTROL GRIDDLE TOP
25	36", 24", 18" & 12" WORK TOP
27	36" AND 18" STEP UP OPEN TOP BURNER
29	36" 6 OPEN TOP STEP UP BURNER
31	STEP UP BURNER ASSEMBLY




Fig. 1

"B" MODEL 36", 24", 18", 12" CABINET BASE

"B" MODEL 36", 24", 18", 12" CABINET BASE

ILLUS.	PART NO.	NAME OF PART	AMT.
		PL-F37419 FIG-1	
1	00-958087-000G4	Door Assy. L/H (36" Base Cabinet Only).....	1
	00-958087-000G3	Door Assy. (24" Base Cabinet Only).....	1
	00-958087-000G2	Door Assy. (18" Base Cabinet Only).....	1
	00-958087-000G1	Door Assy. (12" Base Cabinet Only).....	1
2	00-958087-000G5	Door Assy. R/H.....	1
3	00-499740-00001	Bracket - Cabinet Door Magnet.....	1
4	00-497296-00001	Magnet - Door.....	2
5	00-499744-000G1	Support - Shelf.....	2
6	00-499747-00001	Shelf (36" Base Cabinet Only).....	1
	00-499747-00002	Shelf (24" Base Cabinet Only).....	1
	00-499747-00003	Shelf (18" Base Cabinet Only).....	1
7	00-408615-00021	Handle - Door Keeler R3122.....	2




Fig. 2

"S" MODEL OVEN

"S" MODEL OVEN

ILLUS.	PART NO.	NAME OF PART	AMT.
	PL-F37419 FIG-2		
1	00-499468-00001	Support - Wire Rack.....	2
2	00-499517-00002	Rack, Oven.....	1
3	00-499467-00001	Oven - Side Liner R/H (Porcelain).....	1
3A	00-499467-00003	Oven - Side Liner R/H (SST).....	1
4	00-499467-00002	Oven - Side Liner L/H (Porcelain).....	1
4A	00-499467-00004	Oven - Side Liner L/H (SST).....	1
5	00-499800-000G1	Bottom Liner (Porcelain).....	1
5A	00-499800-000G2	Bottom Liner (SST).....	1
6	00-405930-00001	NLA - Obsolete--Eyelet - Brass.....	1
7	00-499513-000G3	Door (Porcelain) less handle.....	1
7A	00-499513-000G4	Door (SST) less handle.....	1
8	00-956635-00001	Handle - Oven Door.....	1
9	00-404079-0000F	Nozzle, 90 Deg. Burner.....	1
10	00-497891-00001	Burner - Oven.....	1
11	00-412787-00001	Pilot - Oven (NAT).....	1
	00-412787-00002	Pilot - Oven (LP).....	1
12	00-010901-00031	Orifice - Spud (31 Drill) (Sea Level - 2499 Ft.).....	1
	00-010901-00047	Orifice - Spud (47 Drill) (Sea Level - 2499 Ft.).....	1
14	00-499554-00001	Disconnect - Main Male Q.....	1
15	00-497906-00001	Bearing - Pillow Block.....	2
16	00-499512-000G3	Counterweight - Oven L.H.....	1
	00-499512-000G4	Counterweight - Oven R.H.....	1
17	00-499452-00001	Coverplate.....	1
18	00-958353-00001	Cover - Moulian Panel.....	1
19	00-958470-000G1	Kick Panel.....	1
20	00-499507-00001	Panel - Oven Control.....	1
21	00-413157-00001	Knob - Shut Off.....	1
22	00-497883-00001	Bracket - Thermostat Bulb.....	1
23	00-414708-00001	Plate - On-Off.....	1
24	00-499168-00001	Knob - Oven 650 Deg. F.....	1
	00-499168-00002	Knob - Oven 550 Deg. F.....	1
	00-413112-00012	Leg (6 In.).....	4
	00-497001-00001	Caster (Without Brake).....	AR
	00-497001-00002	Caster (With Brake).....	AR




FIG. 3

"S" MODEL GAS MANIFOLD ASSY

"S" MODEL GAS MANIFOLD ASSY

ILLUS.	PART NO.	NAME OF PART	AMT.
	PL-F37419 FIG-3		
1	00-497765-00001	Valve - Pilot Safety.....	1
2	00-407522-00007	Thermosat - 550 Deg. F.....	1
	00-407522-00008	Thermostat - 400-650 Deg. F.....	1
3	00-719971	Valve - Gas Manual Shut-Off.....	1
4	FP-035-54	Pipe - 3/8 X 2.250 (BLKSTL) (TBE).....	1
5	FP-012-21	Elbow 90 Deg. (1/8 Male Pipe x 1/4 Tube).....	2
6	00-719132	Union - 3/8" (BLKSTL) (150#).....	1
7	FP-085-68	Fitting- Elbow (7/16 TBG X 3/8 MPT).....	1
8	FP-019-10	Tee - 3/8 X 3/8 X 3/8 (BLKSTL).....	1
9	00-404193-00001	Valve - Pilot 260 BROILER.....	1
10	00-719066	Bushing - Pipe 3/8 -1/8.....	1
11	SD-032-07	Self-Tapping Screw 10-24 x 1/2 Hex Washer Hd., Type TT.....	1
12	NS-044-09	Nut Assy. 10-24 Hex Keps.....	1
13	FP-012-03	Fitting - Elbow 1/2 TBG X 3/8 MPT.....	1
14	SC-060-38	Cap Screw 1/4-20 X 5/8 Hex Hd.....	1
15	00-499465-00001	Bracket - Gas Mounting.....	1
16	00-426505-00009	Tube - Flex 1/4" O.D. 9" Lg.....	1
17	FP-035-46	Pipe 3/8 x 1 Lg. TBE.....	1
18	00-426509-00024	Tube - Flex 1/2" O.D. 24" Lg.....	1
19	00-426508-00048	Tube - Flex 7/16" O.D. 48" Lg.....	1
20	00-426505-00036	Tube - Flex 1/4" O.D. 36" Lg.....	1
21	00-412788-00004	Thermocouple - 48" Lg. 48" Lg.....	1




Fig. 4

"C" MODEL OVEN

"C" MODEL OVEN

ILLUS.	PART NO.	NAME OF PART	AMT.
	PL-F37419 FIG-4		
1	00-499468-00002	Support - Wire Rack R.H.....	1
	00-499468-00003	Support - Wire Rack L.H.....	1
2	00-499517-00002	Rack, Oven.....	2
3	00-499547-000G1	Motor - 1/6 HP, 120V.....	1
4	00-415780-00008	Wheel - Blower (Incls. Set Screws).....	1
5	00-499641-00001	Grate - Motor Convection Oven.....	1
6	00-404079-0000F	Nozzle, 90 Deg. Burner.....	1
7	00-010901-00042	Orifice - Spud (Drill 42) (Nat.) (Sea Level - 2499 FT.).....	1
	00-010901-00051	Orifice - Spud (51 Drill) Orifice - Spud (Drill 51) (Pro) (Sea Level - 2499 Ft.).....	1
8	00-497891-00001	Burner - Oven.....	1
9	00-412787-00001	Pilot - Oven (NAT).....	1
	00-412787-00002	Pilot - Oven (LP).....	1
10	00-956633-00002	Bracket - Switch Door.....	1
11	00-411496-000F1	Switch - Micro Door.....	1
12	00-405016-00001	Cord - Electric Supply (120 V. Only).....	1
13	00-499554-00001	Disconnect - Main Male Q.....	1
14	00-499513-000G3	Door (Porcelain) less handle.....	1
14A	00-499513-000G4	Door (SST) less handle.....	1
15	00-956635-00001	Handle - Oven Door.....	1
16	00-499512-000G6	Counterweight - Oven Convection R.H.....	1
	00-499512-000G3	Counterweight - Oven L.H.....	1
17	00-499452-00001	Coverplate.....	1
18	00-497906-00001	Bearing - Pillow Block.....	1
19	00-958353-00001	Cover - Moulian Panel.....	1
20	00-499507-00003	Cover - Control Panel.....	1
21	00-957464-00001	Guard - Thermostat.....	1
22	00-411506-00015	Thermostat (200-550 Deg. F).....	1
23	00-497883-00002	Bracket - Thmostat Bulb.....	1
24	00-413157-00001	Knob - Shut Off.....	1
25	00-499168-00003	Knob - Oven 550F Convection.....	1
26	00-715112	Switch - Rocker, Lighted.....	1
27	00-957609-00001	Label - On - Off Cool Down.....	1
28	00-414708-00001	Plate - On-Off.....	1
29	00-499515-000G1	Kick Plate Assy.....	1
*	00-497694-00001	Wiring Diagram.....	1
*	00-497698-00001	Decal - Wire Schematic.....	1

* Not Shown




Fig. 5

"C" MODEL GAS MANIFOLD ASSY

"C" MODEL GAS MANIFOLD ASSY

ILLUS.	PART NO.	NAME OF PART	AMT.
	PL-F37419	FIG-5	
1	00-499651-00003	Bracket - Mounting Gas (Convection).....	1
2	00-497765-00001	Valve - Pilot Safety - Basso.....	1
3	FP-035-47	PIPE - 3/8 X 1.125 (TBE) (BLKSTL).....	1
4	00-428045-00001	Gas Solenoid Valve.....	1
5	00-719971	Valve - Gas Manual Shut-Off.....	1
6	FP-019-10	Tee - 3/8 X 3/8 X 3/8 (BLKSTL).....	1
7	FP-085-68	Fitting- Elbow (7/16 TBG X 3/8 MPT).....	1
8	00-956615-00002	Bracket - Manifold Support.....	1
9	SC-060-38	Cap Screw 1/4-20 X 5/8 Hex Hd.....	1
10	NS-044-09	Nut Assy. 10-24 Hex Keps.....	1
11	SD-032-07	Self-Tapping Screw 10-24 x 1/2 Hex Washer Hd., Type TT.....	1
12	FP-012-03	Fitting - Elbow 1/2 TBG X 3/8 MPT.....	1
13	FP-012-21	Elbow 90 Deg. (1/8 Male Pipe x 1/4 Tube).....	1
14	00-404193-00001	Valve - Pilot.....	1
15	FP-026-04	Bushing - Pipe 3/8 to 1/8.....	1
16	00-426505-00006	Tube - Flex (1/4 x 6 In.).....	1
17	00-426509-00024	Tube - Flex 1/2" O.D. 24" Lg.....	1
18	00-426508-00048	Tube - Flex 7/16" O.D. 48" Lg.....	1
19	00-426505-00036	Tube - Flex 1/4" O.D. 36" Lg.....	1
20	00-412788-00004	Thermocouple - 48" Lg.....	1




Fig. 6

36", 24" & 12" OPEN TOP BURNER

36", 24" & 12" OPEN TOP BURNER

ILLUS.	PART NO.	NAME OF PART	AMT.
	PL-F37419 FIG-6		
1	00-957575-00001	Cover - Manifold 36" (6 Open Top Burner).....	1
	00-957570-00001	Cover Manifold 24" (4 Open Top Burner).....	1
	00-957559-00001	Cover - Manifold 12" (2 Open Top Burner).....	1
2	00-499006-000G2	Tray - Crumb (SST) 36" (6 Open Top Burner).....	1
	00-956724-000G2	Tray - Crumb (SST) 24" (4 Open Top Burner).....	1
	00-499969-000G2	Tray - Crumb (SST) 12" (2 Open Top Burner).....	1
3	00-426509-00010	Tube - Flex 1/2" O.D. 10" Lg.....	1
4	00-499555-00001	Disconnect - Gas Female.....	1
5	00-499047-00001	Bracket - Disconnect.....	1
6	FP-012-02	Fitting - Tube 1/2 TBG X 3/8 MPT.....	1
7	00-497984-00001	Retainer - Grate.....	2
8	00-499425-000G1	Front Top Assy. 36" (6 Open Top Burner).....	1
	00-956705-000G1	Front Top Assy. 24" (4 Open Top Burner).....	1
	00-499966-000G1	Front Top Assy. 12" (2 Open Top Burner).....	1
9	00-957235-000G1	Front Top Assy - Condiment Rail 36" (6 Open Top Burner).....	1
	00-957239-000G1	Front Top Slide Rail Assy. 36" (6 Open Top Burner).....	1
	00-957357-000G1	Front Top Assy. - Condiment Rail 24" (4 Open Top Burner).....	1
11	00-499493-00001	Support - Grate (Alum.).....	1
	00-499493-00002	Support - Grate (SST).....	1
12	00-499001-00002	Support - HD Burner (SST) 36" (6 Open Top Burner).....	1
	00-956718-00002	Support - HD Burner (SST) 24" (4 Open Top Burner).....	1
	00-499965-00002	Support - HD Burner (SST) 12" (2 Open Top Burner).....	1
13	00-499002-00003	Deflector - HD Splash L.H. (SST).....	1
	00-499002-00004	Deflector - HD Splash R.H. (SST).....	1
14	00-499615-00002	Deflector - Rear (SST) 36" (6 Open Top Burner).....	1
	00-956725-00002	Deflector - Rear (SST) 24" (4 Open Top Burner).....	1
	00-499935-00001	Deflector - Rear (SST) 12" (2 Open Top Burner).....	AR
15	00-957368-00001	Grate - Front 12".....	AR
16	00-957369-00001	Grate - Rear 12".....	AR
17	00-957341-00001	Bowl - Rear 12" Double.....	AR
18	00-499712-00001	Knob - HD Burner.....	AR
19	00-957367-00001	Valve - Burner.....	AR
20	00-499970-00001	Valve - Pilot Quick Disconnect.....	AR
21	00-957343-00002	Burner - Head 6".....	AR
22	00-957342-00001	Venturi Assy.....	AR
23	00-402558-00004	Clip - Tubing.....	AR
24	00-958073-00002	Plate - Restrictor.....	AR
25	00-959108-000G1	Pilot - Kit Open Top Burners.....	AR
*	00-957067-000G1	Riser - Stub 36" W/Alum. Back 36" (6 Open Top Burner).....	1
*	00-957066-000G1	Riser - Stub 24" W/Alum. Back 24" (4 Open Top Burner).....	1
*	00-957064-000G1	Riser - Stub 12" W/Alum. Back 12" (2 Open Top Burner).....	1

* Not Shown





Fig. 7

36"- 4 & 18"- 2 OPEN TOP BURNER

36"- 4 & 18"- 2 OPEN TOP BURNER

ILLUS.	PART NO.	NAME OF PART	AMT.
	PL-F37419 FIG-7		
1	00-957573-00001	Manifold Cover 36" (4 Open Top Burner).....	1
	00-957564-00001	Manifold Cover 18" (2 Open Top Burner).....	1
2	00-499006-000G2	Tray - Crumb (SST) 36" (4 Open Top Burner).....	1
	00-956696-000G2	Tray - Crumb (SST) 18" (2 Open Top Burner).....	AR
3	00-497984-00001	Retainer - Grate.....	2
4	00-426509-00010	Tube - Flex 1/2" O.D. 10" Lg.....	1
5	00-499555-00001	Disconnect - Gas Female.....	1
6	00-499047-00001	Bracket - Disconnect.....	1
7	00-499425-000G1	Front Top Assy. 36" (4 Open Top Burner).....	1
	00-957235-000G1	Front Top Assy - Condiment Rail 36" (4 Open Top Burner).....	4
	00-956658-000G1	Front Top Assy 18" (2 Open Top Burner).....	AR
8	00-957239-000G1	Front Top Slide Rail Assy.....	4
10	00-499001-00004	Support - (4) OTB Burner (SST).....	1
	00-956690-00001	Support - (2) OTB Burner (SST).....	1
11	00-499493-00001	Support - Grate (Alum.).....	1
	00-499493-00002	Support - Grate (SST).....	1
12	00-499615-00002	Deflector - Rear (SST) 36" (4 Open Top Burner).....	1
	00-956697-00002	Deflector - Rear (SST) 36" (4 Open Top Burner).....	1
13	00-957370-00001	Grate - Front 18".....	AR
14	00-957371-00001	Grate - Rear 18".....	AR
15	00-957372-00001	Bowl - 18" Double.....	AR
16	00-957343-00002	Burner - Head 6".....	AR
17	00-499712-00001	Knob - HD Burner.....	AR
18	00-957367-00001	Valve - Burner.....	AR
19	00-499970-00001	Valve - Pilot Quick Disconnect.....	AR
20	00-957398-000G1	Venturi Assy.....	1
21	00-402558-00004	Clip - Tubing.....	AR
22	00-958073-00001	Plate - Restrictor.....	1
23	00-959108-000G1	Pilot - Kit Open Top Burners.....	1
24	FP-012-02	Fitting - Tube 1/2 TBG X 3/8 MPT.....	1
25	00-499002-00003	Deflector - HD Splash L.H. (SST).....	1
	00-499002-00004	Deflector - HD Splash R.H. (SST).....	1
*	00-957067-000G1	Riser - Stub 36" W/Alum. Back 36" (4 Open Top Burner).....	1
*	00-957065-000G1	Riser - Stub 18" W/Alum. Back 36" (4 Open Top Burner).....	1


* Not Shown



36" & 24" CHAR BROILER

36" & 24" CHAR BROILER

ILLUS.	PART NO.	NAME OF PART	AMT.
	PL-F37419 FIG-8		
1	00-957574-00001	Cover - Manifold 36" Char Broiler.....	1
	00-957567-00001	Cover - Manifold 24" Char Broiler.....	1
2	00-499006-000G2	Tray - Crumb (SST) 36" Char Broiler.....	1
	00-956724-000G2	Tray - Crumb (SST) 24" Char Broiler.....	1
3	00-499555-00001	Disconnect - Gas Female.....	1
4	00-499047-00001	Bracket - Disconnect.....	1
5	00-957814-00001	Valve - Dual Pilot.....	1
6	00-788541-0000A	Tube - Pilot, Flex (W/Tip).....	1
7	00-499425-000G1	Front Top Assy. 36" Char Broiler.....	1
	00-956705-000G1	Front Top Assy. 24" Char Broiler.....	1
8	00-957235-000G1	Front Top Assy - Condiment Rail 36" Char Broiler.....	1
	00-957239-000G1	Front Top Slide Rail Assy. 36" Char Broiler.....	1
	00-957357-000G1	Front Top Assy. - Condiment Rail 24" Char Broiler.....	1
9	00-412852-00001	Grate - Top Straight.....	6
	00-722121	Grate - Slanted 6-RIB 24" Char Broiler.....	2
10	00-710407	Radiant.....	6
11	00-956614-00002	Supercharger.....	5
12	00-418051-0000F	Hood - Orifice.....	6
13	00-957413-00001	Burner Assy.....	6
14	00-710455	Burner Rod.....	6
15	FP-012-02	Fitting - Tube 1/2 TBG X 3/8 MPT.....	1
16	00-426509-00010	Tube - Flex 1/2" O.D. 10" Lg.....	1
17	00-499712-00001	Knob - HD Burner.....	3
18	00-719383	W/O Plug.....	6
19	00-722425	Tubing - Flex 3/8" X 8" Lg.....	3
20	00-957348-00001	Valve - Gas.....	3
21	00-717676	Tee - Tube 3/8".....	1
22	00-722468	NLA - Obsolete--3/8" Tube 1-1/4" Long.....	1
23	00-956748-00001	Heat Deflector.....	6
24	00-957412-00001	Bracket - Dual Pilot.....	AR
25	00-957335-00001	Stabilizer - Burner.....	6
26	00-719329	Air Mixer Assy.....	6
27	00-499615-00002	Deflector - Rear (SST) 36" Char Broiler.....	1
	00-956725-00002	Deflector - Rear (SST) 24" Char Broiler.....	1
28	00-497984-00001	Retainer - Grate.....	2
	00-957067-000G1	Riser - Stub 36" W/Alum. Back 36" Char Broiler.....	1
	00-957066-000G1	Riser - Stub 24" W/Alum. Back 24" Char Broiler.....	1



36" & 18" FRENCH TOP RADIAL FIN HOT TOP

36" & 18" FRENCH TOP RADIAL FIN HOT TOP

ILLUS.	PART NO.	NAME OF PART	AMT.
	PL-F37419 FIG-9		
1	00-957576-00001	Cover - Manifold W/Rail 36" Radial Fin. Hot Top.....	1
	00-957563-00001	Cover Manifold 18" Radial Fin. Hot Top.....	1
2	00-499425-000G1	Front Top Assy. 36" Radial Fin. Hot Top.....	1
	00-956658-000G1	Front Top Assy 18" Radial Fin. Hot Top.....	1
3	00-957235-000G1	Front Top Assy - Condiment Rail.....	1
	00-957239-000G1	Front Top Slide Rail Assy.....	1
4	00-499814-00001	Casting - LH Radial Fin. 36" 36" Radial Fin. Hot Top.....	1
	00-956800-00001	Casting - Radial Fin. 18" Radial Fin. Hot Top.....	1
5	00-499814-00002	Casting - RH Radial Fin. 36".....	1
6	00-400705-00001	Ring - TOP.....	1
7	00-715211-000GR	Plate - Top.....	1
8	00-956809-00002	Deflector - Radial Fin. Rear 36" Radial Fin. Hot Top.....	1
	00-956663-00001	Deflector - Radial Fin. 18" Radial Fin. Hot Top.....	1
9	00-956622-000G1	Brick Set 36" Radial Fin. Hot Top.....	1
	00-956799-000G1	Brick Set 18" Radial Fin. Hot Top.....	1
10	00-497984-00001	Retainer - Grate.....	1
11	00-719383	Elbow 3/8 Orifice W/O Plug.....	1
12	00-499810-00002	Bracket - Pilot.....	1
13	00-957801-000G1	Burner - Inner, Radial Fin 36" Radial Fin. Hot Top.....	1
	00-956794-00001	Burner - 18" Inner 18" Radial Fin. Hot Top.....	1
14	00-957946-000G1	Plate - Aeration Assy. 36" Radial Fin. Hot Top.....	1
	00-957710-000G1	Plate - Aeration, Assy. 18" Radial Fin. Hot Top.....	1
15	00-409413-00001	Burner - Casting 36" Radial Fin. Hot Top.....	1
	00-956793-00001	Burner - 18" Outer 18" Radial Fin. Hot Top.....	1
16	00-409412-00001	Burner - Casting.....	1
17	FP-012-02	Fitting - Tube 1/2 TBG X 3/8 MPT.....	1
18	00-426509-00010	Tube - Flex 1/2" O.D. 10" Lg.....	1
19	00-499047-00001	Bracket - Disconnect.....	1
20	00-408379-00003	Valve - Burner.....	3
21	00-957814-00001	Valve - Dual Pilot.....	1
22	00-499712-00001	Knob - HD Burner.....	3
23	00-499555-00001	Disconnect - Gas Female.....	1
	00-426509-00018	Tube - Flex 1/2" O.D. 18" Lg.....	3
	00-426505-00014	Tube - Flex 1/4" O.D. 14" Lg.....	2




Fig. 10

36", 24" & 18" THERMO CONTROL GRIDDLE TOP

36", 24" & 18" THERMO CONTROL GRIDDLE TOP

ILLUS.	PART NO.	NAME OF PART	AMT.
	PL-F37419 FIG-10		
1	00-957961-00001	Panel - Rear Closure 36" (Alum.) 36" Griddle Top.....	1
	00-957989-00001	Panel - Rear Closure 24" 24" Griddle Top.....	1
	00-957993-00001	Panel - Rear Closure 18" 18" Griddle Top.....	AR
2	00-499047-00001	Bracket - Disconnect.....	1
3	00-499555-00001	Disconnect - Gas Female.....	1
4	00-426509-00010	Tube - Flex 1/2" O.D. 10" Lg.....	1
5	00-499425-000G1	Front Top Assy. 36" Griddle Top.....	1
	00-956705-000G1	Front Top Assy. 24" Griddle Top.....	1
	00-956658-000G1	Front Top Assy 18" Griddle Top.....	1
6	00-957235-000G1	Front Top Assy - Condiment Rail 36" Griddle Top.....	1
	00-957239-000G1	Front Top Slide Rail Assy. 36" Griddle Top.....	1
	00-957357-000G1	Front Top Assy. - Condiment Rail 24" Griddle Top.....	1
	00-957235-000G1	Front Top Assy - Condiment Rail 18" Griddle Top.....	1
7	00-499112-00001	Bracket - Griddle Burner Support.....	3
8	00-499635-00001	Griddle Burner Assy.....	3
9	00-413302-00001	Clip - Pilot Mounting.....	3
10	00-497984-00001	Retainer - Grate.....	2
11	00-957982-000G4	Grease Drawer Assy. 36" Griddle Top.....	1
	00-956709-000G4	Grease Drawer Assy. 24" Griddle Top.....	1
	00-956677-000G4	Grease Drawer Assy. 18" Griddle Top.....	1
12	00-499622-000G2	NLA - Obsolete--36" Griddle Assy.....	1
	00-499957-000G2	NLA - Obsolete--24" Griddle Assy.....	1
	00-956674-000G2	NLA - Obsolete--18" Griddle Assy.....	1
13	00-957170-000G1	Griddle Baffle Assy. Center (Not Shown).....	2
14	00-956662-00001	Cover - Rear Manifold.....	1
	00-956710-00001	Cover - Hot Top 24" Griddle.....	1
15	00-499488-00002	Knob - Gas Thermostat.....	3
16	FP-012-02	Fitting - Tube 1/2 TBG X 3/8 MPT.....	1
17	00-404193-00001	Valve - Pilot.....	3
18	00-499488-00001	Thermostat - Gas.....	3
19	FP-085-68	Fitting- Elbow (7/16 TBG X 3/8 MPT).....	6
20	00-404079-0000F	Nozzle.....	3
21	00-418051-0000F	Hood - Orifice.....	3
22	FP-085-42	Fitting - Tube (7/16 TBG X 3/8 MPT).....	3
23	00-426508-00006	Tube - Flex 7/16" O.D. 6" Lg.....	3
24	00-426508-00010	Tube - Flex 7/16" O.D. 10" Lg.....	3
25	SD-036-79	Self-Tapping Screw 6-32 x 1/2 Type TT Hex Hd. (SST).....	6
26	FP-085-53	Pipe Plug 1/8.....	1
27	00-957604-000G2	Cover - Manifold 36" Thermo Griddle (Condiment Rail).....	1
	00-957602-000G2	Cover - Manifold 24" Thermo Griddle (Condiment Rail).....	1
	00-957594-000G1	Cover - Manifold 18" Thermo Griddle.....	1
28	00-957396-00002	Baffle - Griddle.....	1
	00-957988-00002	Baffle - 24" Forward Griddle.....	1
	00-957992-00002	Baffle - 18" Forward Griddle.....	1
29	00-788541-0000A	Tube - Pilot, Flex (W/Tip) (Not Shown).....	2
30	00-956939-00002	Tube - Pilot, Flex (W/Tip) (Not Shown).....	1




Fig. 11

36", 24", 18" & 12" WORK TOP

36", 24", 18" & 12" WORK TOP

ILLUS.	PART NO.	NAME OF PART	AMT.
PL-F37419 FIG-11			
1	00-497984-00001	Retainer - Grate.....	2
2	00-499615-00002	Deflector - Rear (SST) 36" Work Top.....	1
	00-956725-00002	Deflector - Rear (SST) 24" Work Top.....	1
	00-956697-00002	Deflector - Rear (SST) 18" Work Top.....	1
	00-499935-00002	Deflector - Rear (SST) 12" Work Top.....	1
3	FP-012-02	Fitting - Tube 1/2 TBG X 3/8 MPT.....	1
4	00-426509-00010	Tube - Flex 1/2" O.D. 10" Lg.....	1
5	00-957590-00001	Cover Manifold 36" Work Top.....	1
	00-957572-00001	Cover Manifold 24" Work Top.....	1
	00-957566-00001	Cover - Manifold 18" Work Top.....	1
	00-957558-00001	Cover - Manifold 12" Work Top.....	1
6	00-956639-000G1	Work Top Assy. 36".....	1
	00-956639-000G2	Work Top Assy. 24".....	1
	00-956639-000G3	Work Top Assy. 18".....	1
	00-956639-000G4	Work Top Assy. 12".....	1
7	00-499555-00001	Disconnect - Gas Female.....	1
8	00-499047-00001	Bracket - Disconnect.....	1
9	00-499425-000G1	Front Top Assy. 36" Work Top.....	1
	00-957235-000G1	Front Top Assy - Condiment Rail 36" Work Top.....	1
	00-956705-000G1	Front Top Assy. 24" Work Top.....	1
	00-957357-000G1	Front Top Assy. - Condiment Rail 24" Work Top.....	1
	00-956658-000G1	Front Top Assy 18" Work Top.....	1
	00-499966-000G1	Front Top Assy. 12" Work Top.....	1
*	00-957067-000G1	Riser - Stub 36" W/Alum. Back.....	1
*	00-957066-000G1	Riser - Stub 24" W/Alum. Back.....	1
*	00-957065-000G1	Riser - Stub 18" W/Alum. Back.....	1
*	00-957064-000G1	Riser - Stub 12" W/Alum. Back.....	1

* Not Shown




Fig. 12

36" AND 18" STEP UP OPEN TOP BURNER

36" AND 18" STEP UP OPEN TOP BURNER

ILLUS.	PART NO.	NAME OF PART	AMT.
PL-F37419 FIG-12			
1	00-957882-00001	Bowl - Front 18" Step Up.....	2
2	00-957881-00001	Bowl - Rear 18: Step Up.....	2
3	00-957877-000G1	Frame - 18" Step Up.....	2




Fig. 13

36" 6 OPEN TOP STEP UP BURNER

36" 6 OPEN TOP STEP UP BURNER

ILLUS.	PART NO.	NAME OF PART	AMT.
PL-F37419 FIG-13			
1	00-957878-00001	Bowl - 12" Front.....	1
2	00-958879-00001	Bowl - 12" Rear.....	1
3	00-957877-000G1	Frame - 18" Step Up.....	1
4	00-957817-000G1	Burner Assy. - Step Up.....	AR
5	00-957880-00001	Support - Burner Step Up.....	AR




Fig.14

STEP UP BURNER ASSEMBLY

STEP UP BURNER ASSEMBLY

ILLUS.	PART NO.	NAME OF PART	AMT.
		PL-F37419 FIG-14	
1	00-957817-000G1	Burner Assy. - Step Up.....	1
2	00-957826-00001	Burner - Rear Step Up.....	1
3	00-957825-00001	Elbow - Center Step Up.....	1
4	00-957824-00001	Burner - Front Step Up.....	1
5	00-957823-00001	Gasket.....	1
6	00-959108-000G2	Pilot Assy. - Step Up.....	1

